


UG-38N SERIES DIE GRINDERS

EXPLODED VIEW




Handle Body Assembly

Code 505-983-1

Components

(#1, 2, 3, 4, 5, 6, 7, 52)




Handle Body Assembly

Code 506-003-2

Components

(#8, 9, 10, 11, 12, 13, 14, 15)



PARTS LIST

Index No.	Code No.	Parts Name	Quantity	Index No.	Code No.	Parts Name	Quantity	Index No.	Code No.	Parts Name	Quantity
505-983-1 Handle Body Assembly (UG-38N, UG-38NL, UG-38NA)				#19	505-286-1	Cylinder	1	#43	982-101-0	Bad (Bearing (6001)	1
#1	504-014-4	○ Handle Body	1	#20	505-287-1	Rotor	1	#44	988-290-0	Needle Roller Bearing (TA-1215)	1
#2	601-108-1	○ Valve Plug	1	#21	505-288-1	Blade	4	PARTS FOR US-38NA, 38NSA			
#3	505-914-2	○ Self-locking Valve Lever Assembly	1	#22	505-289-1	Front Plate	1	#53	505-025-6	Casing	1
#4	970-239-0	○ Pin (H)(3×21)	1	#27	973-006-0	Roll Pin (2×6)	1	#54	505-395-6	Outer Ring	1
#5	973-124-0	○ Roll Pin (3×24)	1	#28	974-005-0	Key (3×6)	1	#24	505-396-1	Inner Ring	1
#6	976-114-0	○ Spring (6×18)	1	#29	975-023-0	Spacer (11.8×8×2.6)	1	#55	505-782-6	Exhaust Deflector	1
#7	981-207-0	○ Ball (9/32)	1	#30	978-219-0	Snap Ring (22×1.2)	1	#56	507-099-0	Damper Towel for UG-38NSA	1
#25	505-767-2	Casing Cover	1	#31	982-015-0	Ball Bearing (608)	1	#56-1	505-099-7	Damper Towel for UG-38NA	1
#52	990-904-0	○ O-Ring (SNS-6)	1	#32	982-021-0	Ball Bearing (626)	1	#57	505-296-6	Front Plate Spacer	1
506-003-2 Handle Body Assembly (UG-38NS, UG-38NSL, UG-38NSA)				#33	990-914-0	O-Ring (SNS-16)	1	#58	990-917-0	O-Ring (SNS-24)	1
				#34	990-923-0	O-Ring (SNS-26)	1	#59	990-925-0	O-Ring (SNS-32)	1
				PARTS FOR UG-38N, 38NS				#60	979-119-0	Outer Snap Ring (22)	1
#8	506-014-2	× Handle Body	1	#16	505-025-1	Casing	1	#64	710-546-2	Piston	1
#9	506-100-2	× Valve	1	#23	505-395-1	Outer Ring	1	Accessories			
#10	506-090-2	× Air Inlet Bushing	1	#24	505-396-1	Inner Ring	1	#45	940-114-0	Air Hose Nipple (NPT 1/4×3/8)	1
#11	506-015-2	× Valve Handle	1	#26	505-782-1	Exhaust Deflector	1	#46	942-114-0	Connecting Screw (1/4×NPT1/4)	1
#12	971-224-0	× Pin (3×24)	1	PARTS FOR UG-38NL, 38NSL				#47	505-412-1	Chuck Nut	1
#13	976-022-0	× Spring (3×5.5)	1	#35	507-025-1	Casing	1	#48	923-510-0	Collect Chuck Assembly (3)	1
#14	977-080-0	× Cone Spring (7×18×10)	1	#36	507-033-1	Wheel Spindle Casing	1		923-512-0	Collect Chuck Assembly (6)	1
#15	981-002-0	× Ball (1/8)	1	#37	507-395-1	Outer Ring	1		923-515-0	Collect Chuck Assembly (1/8)	1
#25-1	505-767-1	Casing Cover	1	#38	507-366-2	Clutch	1		923-516-0	Collect Chuck Assembly (1/4)	1
UG-38N SERIES COMMON PARTS				#39	507-338-1	Clutch Stand	1	#49	936-514-0	Spanner (14)	2
#17	505-285-2	Rear Plate	1	#40	507-390-3	Wheel Spindle	1	#50	939-101-0	Spanner (55×17.5×120)	1
#18	505-291-1	Rear Plate Spacer	1	#41	507-074-1	Wheel Spindle Casing	1				
				#42	975-236-0	Spacer (30×21×4)	1				

When ordering spare parts, please specify tool type, code number and parts name.

Printed in Japan



URYU SEISAKU, LTD. Osaka, Japan

For further information, please contact at any time your nearest URYU distributor.

OKA-106-17-11-16-5030